

PRODUCT	NO./ M2 or L/M	NO./ TONNE	NO./ PALLET	DEL'D PRICE BRIS & S/SHINE		DEL'D PRICE GOLD COAST	
				EACH	M2	EACH	M2
TRENDSTONE BLOCK - 400LX200HX245D COLOURS: IVORY, FRASER CORAL & FRASER SAND	12.5	48	78	\$9.82	\$122.75	\$10.39	\$129.87
TRENDSTONE BLOCK - 400LX200HX245D COLOURS: CHARCOAL & PEBBLE	12.5	48	78	\$9.00	\$112.50	\$9.64	\$120.50
TRENDSTONE CORNER - 390LX190WX200H IVORY, FRASER CORAL & FRASER SAND	—	49.5	75	\$9.82	—	\$10.39	—
TRENDSTONE CORNER - 390LX190WX200H CHARCOAL & PEBBLE	—	49.5	75	\$9.00	—	\$9.64	—
TRENDSTONE CAP - 400LX65HX255D IVORY, FRASER CORAL & FRASER SAND	2.5/LM	71.5	120	\$6.19	—	\$6.58	—
TRENDSTONE CAP - 400LX65HX255D CHARCOAL & PEBBLE	2.5/LM	71.5	120	\$5.82	—	\$6.23	—

DELIVERY CONDITIONS: (delivery should be scheduled within 3-4 days of ordering)

Brisbane: There is a min. delivery surcharge of \$90 for deliveries less than 2 full pallets. Deliveries south of Pimpama and west of Maclean attract the Gold Coast rate. i.e. Coomera, Pimpama & Maclean attracts the Gold Coast rate.

NB: Please be mindful of post codes that begin with 42... Deliveries to post code areas between 4205 to 4208 attract the Brisbane delivery rate and deliveries to areas between 4209 to 4230 attract the Gold Coast delivery rate.

Gold Coast Area: There is a minimum delivery surcharge of \$110 for deliveries less than 2 pallets.

The Gold Coast area is considered to be the area south of Pimpama (including Pimpama) and North of Tweed Heads.



FRASER CORAL



FRASER SAND



IVORY



PEBBLE



CHARCOAL



CAP



CORNER

Scan QR code to view details on all Nuway store's



ASHMORE
PH: 5597 3433

ashmore@nuway.com.au

BURPENGARY
PH: 3888 8806

burpengary@nuway.com.au

CHANDLER
PH: 3390 2477

chandler@nuway.com.au

FORESTDALE
PH: 3800 5433

forestdale@nuway.com.au

LOGAN
PH: 3808 8442

logan@nuway.com.au

MANGO HILL
PH: 3491 6372

mangohill@nuway.com.au

ORMEAU
PH: 5546 7703

ormeau@nuway.com.au

PINE RIVERS
PH: 3881 1447

pinerivers@nuway.com.au

REDLANDS
PH: 3207 7800

redlands@nuway.com.au

WESTERNS
PH: 3715 6200

westerns@nuway.com.au

INSTALLATION GUIDE

You will need:.....

- Eye Protection
- Spirit Level
- Drainage material for back fill
- Stake and strings
- Road base and Course Sand for leveling pad
- Rubber mallet and bolster
- Mechanical plate compacter (optional)

STEP 1: Dig your retaining wall trench approx. 400mm (16") wide and 150mm (6") deep and fill with 100mm (4") base material such as road base

STEP 2: Compact base

STEP 3: Cover road base with approx. 25mm (1") of crusher dust or course sand and screed to a true level using a spirit level.

Note: Where a concrete base is used allow to harden before proceeding.

STEP 3: Place blocks side by side and front to back on the leveling pad using a string line along the back of the blocks for alignment.

Using a spirit level ensure the first row is level.

STEP 4: If the retaining wall requires an agricultural drain, place it at the bottom of the first course with a gentle fall. Cover pipe or strip drain and surround with a free draining material such as 20mm drainage gravel.

STEP 5: Lay second and subsequent courses following the same procedure. Lock in each block with pins provided.

STEP 6: Backfill with 20mm drainage gravel behind the blocks and compact.

STEP 7: Fit cappers to the retaining wall with masonry adhesive or mortar.

