

INSTALLATION GUIDE

1. **Wall/Substrate Preparation:** The wall/substrate surface should be clean, flush and free of dust and loose particles. Pre-existing surface coatings or paint should be thoroughly removed. It is recommended that a bondcrete sealer is applied to the substrate if the panels are being adhered to a vertical wall.
2. **Choosing an adhesive:** Your local hardware store or Retail Tile outlet will be able to advise you on which adhesive to use as long as you stipulate whether your feature panel is outside, inside or being used in a water feature and that it is being used on stone panels.
3. Using a trowel, evenly apply the adhesive over the entire back of the panel and press the panel into position.
4. Lay your panels in an irregular pattern to avoid emphasising any of the natural defects in the stone. It is for this reason that the stretcher bond is **not** recommended.
5. Use a wet saw with a tile cutting blade for any cuts or mitering.
6. **Sealer:** Application of a penetrating sealer such as Klen's Pinnacle, Tuscan, or Stirling Sealer is recommended on the finished wall.
7. Any future leaching of rust from the stone can be removed easily with Klen's 'Anti-Eff'



ALBANY CREEK
623 Albany Creek Rd
(in Hawkins Centre)
Albany Creek 4035
PH:3325 4533
Albany@nuway.com.au

ASHMORE
650 Southport-Nerang
Road (opp. BP Station)
Ashmore 4214
PH:5597 3433
ashmore@nuway.com.au

CHANDLER
2630 Old Cleveland Rd
(cnr Aldis Street)
Chandler 4155
PH: 3390 2477
chandler@nuway.com.au

LOGAN
488 Loganlea Rd
Slacks Creek 4127
PH:3808 8442
logan@nuway.com.au

MACLEAN
Cnr Mt Lindsay Hwy
and Greenbank Rd
Maclean 4280
PH: 5548 7999
maclean@nuway.com.au

REDLANDS
249 Cleveland-Redland Rd
Thornlands 4164
PH: 3207 7800
redlands@nuway.com.au